AC Adapter

AC Adapter Specifications

Operation	Spec.
Input	100 ~ 240V 1.0A MAX 50~60Hz
Output	+5.0V ⎓ 2.0A

Connecting the AC adapter

Turn the camera off and follow the instructions below:

1. Open the connector cover and connect one end of the AC adapter to the DC-in jack on the camera.

2. Connect the other end to an electrical outlet.

Make sure the AC adapter is accordance with the above specifications to avoid causing damage to the camera.

This camera cannot be used as a battery charger. Do not attempt to charge batteries in the camera.

The following product has been tested and approved for use at the **5V setting**:

Brand: RadioShack. Product: Digital Camera Power Adapter

Catalog #: 273-1696 Model: 273-1696